

HARLOW SCONCE

- Certified electrician recommended for electrical installation.
- Terminal Block not included. Installation may require advice from a qualified person.
- For all LED fixtures, use only with class 2 power unit.
- The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.

*IMPORTANT: Please provide email confirmation that your order and its related components have been received in their entirety and in good condition. Failure to do so within 7 days of delivery will waive all product warranties.

Provided Supplies:


- Harlow Sconce fixture
- Universal T-bar
- Installation Screws
- LED Driver
- Spare LED chip

Required Tools:

- Screwdriver
- 4x 2-pole Wiring Terminals, screw or screwless, 12-18AWG (1.0-2.5mm2), rated for 600V, 15A EX: WAGO 222-412
- Requires LED driver; Input: Local Line Voltage, Output 12Vdc SELV, 5A, Max 60 Watt, Class 2 LED Driver.




Shut-down associated electrical breaker and wire LED driver to power source. Then secure driver in junction box using provided universal T-bar.






Remove the glass retainer by unscrewing both screws as shown below.








Remove the light bulb assembly from the fixture.






Slide the glass into the fixture and screw the glass retainer back in its place.



sales@twentieth.net 323.904.1200 www.twentieth.net



Once the glass is installed, reinstall the bulb assembly through the opening at the bottom of the fixture.





Once steps 1 thru 4 are complete, instal the light fixture on to the junction box by threading the four supplied nuts on to the T-bar.

