Roll & Hill

MAINTENANCE INSTRUCTIONS

Note: Please follow maintenance instructions on how to best clean each material. If you are unsure of a material or have any other maintenance questions, contact our Customer Service department.

Acrylic | Use warm water with microfiber cloth

Aluminum | Use warm water with microfiber cloth

Brass (Finished) | Use warm water with microfiber cloth

Brass (Raw) | Use dry feather duster

Ceramic | Use warm water with microfiber cloth

Fabric | Dust with soft cloth

Glass | Use non-ammonia glass cleaner with microfiber cloth

Marble | Use warm water with microfiber cloth and wipe dry with a second microfiber cloth. Do not allow to air dry as marble is prone to water spots. Do not use vinegar or any acidic solution as these will damage the marble.

Rope | Use dry feather duster

Steel | Use warm water with microfiber cloth

Wood | Use wood oil cleaner and soft cloth

23SEP2021