



SHY Remote Installation Diagram 28-40 Watts



- Transformer and dimmer included.
- When remotely located, access will need to be provided.
- Not to scale.

NOTE:
 For wiring diagram, see "SHY Wiring Diagram - 28-40W"