


# ORACLE

INDOOR PENDANT LUMINAIRE: OR.1.600 / OR.1.900 / OR.1.1200





**WARNING**

ALL ELECTRICAL connections must be made by a qualified electrician in accordance with the regulations and codes governing the area for which the CHRISTOPHER BOOTS Fixture is intended to be installed in. Failure to do so may result in serious harm or damage to property and life, at the owner's liability and expense.

CHRISTOPHER BOOTS will not be held liable for any damage caused from installation.




**WARNING: SHOCK HAZARD**

May result in serious injury or death. Turn off power at circuit breaker before installing the unit.

---

MODEL	WATTS	LAMP	PSU WATTS	PSU VOLTS	FIXTURE WEIGHT	CANOPY WEIGHT	EARTHING (CANOPY)
OR.1.600	36 W	LED	60 W	24 V	4.2 Kg	3.8 Kg	YES
OR.1.900	54 W	LED	100 W	24 V	6.0 Kg	3.8 Kg	YES
OR.1.1200	72 W	LED	100 W	24 V	8.0 Kg	3.8 Kg	YES

PENDANT INSTALLATION GUIDE  
**ORACLE - INDOOR PENDANT LUMINAIRE**



**STEP 1 - ASSEMBLY**


- 1.1 Wearing gloves, unpackage SUSPENSION WIRE / MAGICAL SUSPENSION CABLES, and CEILING CANOPY. Do not unpackage the PENDANT, in order to prevent any damage that may occur during installation.
- 1.2 Ensure that the PENDANT is the right way up as per diagram and that the SUSPENSION WIRE / MAGICAL SUSPENSION CABLES are not tangled.

**STEP 2 - CANOPY INSTALLATION**

- C** ← Fix PSM to ceiling substrate as per **CANOPY INSTALLATION GUIDE**.

**STEP 3 - ELECTRICAL CONNECTION**

- W** ← Connect PSU to 110-240V AC Power as per **WIRING DIAGRAM**.




- C** ← **STEP 4 - PENDANT INSTALLATION**  
Feed the SUSPENSION WIRE / MAGICAL SUSPENSION CABLES through their corresponding positions in the ESCUTCHEON and PSB, as per **CANOPY INSTALLATION GUIDE**.



← **STEP 5 - ELECTRICAL CONNECTION**

Connect the MAGICAL SUSPENSION CABLES to the PSM according to **WIRING DIAGRAM**.



**STEP 6 - FINAL ADJUSTMENTS**

- 6.1 Make adjustments necessary for the desired height and configuration of ORACLE. Ensure that neither the PENDANT or SUSPENSION WIRE / MAGICAL SUSPENSION CABLES are touching each other. *NOTE: Seek client approval before continuing.*
- 6.2 Once ORACLE is hanging in its final position and SUSPENSION WIRE / MAGICAL SUSPENSION CABLES are connected, raise ESCUTCHEON back to the PSM and ensure magnets are engaged.
- 6.3 Carefully remove the protective packaging material. Installation of ORACLE is now complete.

## WARNINGS, CARE & WARRANTY

# ORACLE

*The ORACLE pendant is for indoor use only, and operable to a maximum ambient temperature of 60° celsius. The lamping of this luminaire, is a non-user replaceable source and must only be replaced by CHRISTOPHER BOOTS, an appointed agent and/or qualified professional of CHRISTOPHER BOOTS. Should your pendant require relamping, please email [service@christopherboots.com](mailto:service@christopherboots.com) to make the necessary arrangements.*



**THE LIGHT SOURCE CONTAINED IN THIS LUMINAIRE SHALL ONLY BE REPLACED BY THE MANUFACTURER OR THEIR REPRESENTATIVE AGENT OR A SIMILAR QUALIFIED PERSON**

### CARE INSTRUCTIONS:

ORACLE will require very little maintenance over the years, however changes in appearance of hand applied finishes or unlacquered finishes will vary as these (finishes) are designed to age in appearance. If your ORACLE is treated with care, it will shine brightly for many years to come. We recommend some general tips to help keep it shining its brightest:

- Remove dust by simply running an electrostatic duster or dry cloth every few weeks over all exposed surfaces.
- Under no circumstances should the PENDANT be cleaned with any type of liquids/ detergents or solvents.
- If more than dusting is required, please contact us at: [service@christopherboots.com](mailto:service@christopherboots.com)
- We recommend the use of micro fibre cloths.

## **WARRANTY**

1. CHRISTOPHER BOOTS offers a 36 month / 3 year warranty from date of receipt of balance payment on all light fittings supplied (not installation) against mechanical defects.
2. CHRISTOPHER BOOTS will repair or replace defective components or product within this warranty period.
3. Warranty for componentry includes:
4. LED lamps and strips: 3 years / 36 months after receipt.
5. LED drivers 60w: 3 years / 36 months after receipt.
6. LED drivers 100w + 150w: 5 years / 60 months after receipt.
7. If unsure, please contact [service@christopherboots.com](mailto:service@christopherboots.com)

### **Christopher Boots will not be held responsible for the following:**

1. Damage caused by improper cleaning solutions or methods.
2. Damage caused by improper installation or assembly by customer or customer's agent.
3. Damage caused by improper use of LED.
4. Damage caused by exposure to weather or improper environment - client to check IP rating prior to purchase.
5. Changes in appearance of hand applied finishes or unlacquered finishes.  
*\*Please note that these finishes are designed to age in appearance.*
6. Any costs of installation, removal, or re-installation.
7. Restoration, repair work & any parts purchased separately from supplied PENDANTS.
8. Damage caused during shipping - all items are packed specifically for global transport.

## **DAMAGES**

1. Damages must be documented and reported within 7 business days of receipt.
2. Photo evidence will be required upon reporting of damage claim.
3. CHRISTOPHER BOOTS is not responsible for repair or replacement of damages reported after this time.
4. If damage has occurred in shipping - all packaging must be retained by receiver. Failure to do so may invalidate any claim.

### **Returns:**

1. Because of the hand-made nature of our product, we are not able to offer returns.
2. Warranty claims, however will require client to cover shipping en route back for repair.

#### **A. DEFINITIONS**

In this warranty **Australian Consumer Law** means the Australian consumer law set out in Schedule 2 to the Competition and Consumer Act 2010.

**Goods** means the product or equipment that was purchased in Australia and listed in the Applicable Product Ranges below.

**Manufacturer, We or Us** means:  
CHRISTOPHER BOOTS Pty Ltd  
ABN 20 161 794 574

**Supplier** means the authorized distributor or the licensed electrical contractor that sold you the **Goods**.

**You** means you, the original end-user purchaser of the **Goods**.

#### **B. WARRANTY PERIOD AND DETAILS**

The products detailed above are covered by a warranty against manufacturing faults and defects, provided that:

The product is properly installed, and installation is consistent with the manufacturer's instructions, and is installed by suitably trained and qualified installer. The product is not subjected to any unauthorised modifications.

The product is only used for the purpose of decorative illumination, in line with its designated purpose.

The product use is in normal conditions.

Any faults or defects attributable to the misuse, abuse, accident or non-observance of the manufacturer's instructions on the part of the user are specifically excluded.

#### **C. EXTENT OF THE WARRANTY**

GOODS that prove defective within the Warranty Period by reason or improper workmanship or faulty material, we may, at our own discretion, either repair or replace the GOODS without charge.

This warranty does not cover any cost related to removal, shipping to or from the return point, or reinstallation of the replace or repair item.

Any parts of the GOODS replaced during repairs or any product replaced remain the property of CHRISTOPHER BOOTS Pty Ltd.

In the event of the GOODS being replaced during the WARRANTY PERIOD, the warranty on the replacement GOODS will expire on the same date as the WARRANTY PERIOD of the original GOODS they are replacing.

#### **D. APPLICABLE DATE/COMMENCEMENT OF WARRANTY**

This warranty commences from the date of purchase from the point of purchase from CHRISTOPHER BOOTS Pty Ltd. The details of the point of purchase, as well as all contact information for warranty claims and queries, are detailed below;

CHRISTOPHER BOOTS Pty Ltd.  
369 Gore St. Fitzroy, Vic. Australia 3065  
Ph: +61 3 9417 6501  
Email: service@christopherboots.com

#### **E. CLAIM PROCESS**

The customer claim process is as follows; The customer can make a claim, or enquire about the claim process, by contacting the company as detailed above.

The customer must provide a proof of purchase from the SUPPLIER.

Before returning any goods for a warranty claim, the customer must obtain authorization and a Goods Return Authorisation (GRA) notice. The customer, at their own expense, then forwards the goods, clearly marked with the GRA notice and with provision for return freight, to CHRISTOPHER BOOTS Pty Ltd (see above).

Upon receipt of the goods, CHRISTOPHER BOOTS Pty Ltd will review the claim, and proof of purchase.

If accepted as a valid warranty claim within the terms as described in this document, CHRISTOPHER BOOTS Pty Ltd will either make suitable repairs or provide an equivalent replacement product.

If the claim is rejected, the customer will be provided with a full explanation, and if requested, the goods will be returned.

#### **IMPORTANT:**

**Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.**