





SKLO INSTALLATION INSTRUCTIONS: STEM SCONCE/CEILING 1X LIGHT

GLOVES (NITRILE) ARE PROVIDED AND **MUST BE WORN DURING INSTALLATION TO AVOID FINGERPRINTS ON THE FINISH OF THE EXPOSED METAL PARTS.**

Congratulations on your purchase of a SkLO stem sconce/ceiling 1X light. This product must be installed in accordance with the applicable codes by a person familiar with the construction and operation of the product and the hazards involved, preferably a licensed electrician. Use maximum 7W bulb.

- 1 Carefully unpack all the individual parts and lay them out on a protective surface that will not mar the finishes or scratch the glass. Gloves (nitrile) are provided and must be worn during installation to avoid fingerprints on the finish of the exposed metal parts.
- 2 The threaded socket and canopy will come pre-assembled.
- 3 Install the universal cross bar (provided) to the recessed electrical box with the provided 8/32 thread screws so that the 8/32 threaded holes spaced 2 3/4" on-center on the cross bar are level horizontal.
- 4 Carefully supporting the fixture, connect the exposed leads on the fixture to the leads in the recessed electrical box according to the wiring diagram.
- 5 The canopy installs directly to the crossbar. The back of the canopy is recessed to fit over the crossbar and sit flush against the wall finish surface. Fasten the canopy to the cross bar by screwing the two provided 1" long 8/32 thread machine screws directly into the 8/32 threaded holes space 2 3/4" on-center on the crossbar through the countersunk holes provided in the canopy, making sure that the canopy sits flush against the wall finish surface.
- 6 Install the included light bulb, or the light bulb of your choice (7W max) into the socket.
- 7 Carefully thread the glass sphere onto the socket. Thread the glass sphere on just until they are visually tight - do not overtighten or the sockets can bind or the brass assembly on the glass sphere can loosen.



Wiring diagram